SECTION 6: Wiring Diagrams

CONTENTS

1. Point to Point 6-1
2. Interface Cable Connection 6-2
3. Interface Cable 6-3

1. Point to Point



2. Interface Cable Connection

Interface Cable Connection

Rear Machine Harness
External - to Astro



White to Red
Black to Black
Red to Gray
Yellow to Yellow

Rear Machine Harness
Internal - to Risograph



Red to Mtr . PCB CN 3-15
Black to Mtr. PCB CN5-1,6,7
Gray to Mtr. PCB CN5-9

To Sys. PCB CN9 - 44

This connector is 1 to 1 straight through wiring.

3. Interface Cable